Travis Touch

Quick Guide


Contents

- 2-4 Appearance
 - 5 Specification
- 6-9 Quick Guide
 - 10 Safety Instructions
 - 1 Disclaimer

Limitation of Liability

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WIRTHOW MLL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MODIRES ANDOR CONVEYS THE SOFTWARE AND HARDWARE AS PERMITTED ABOVE, BE LIBBLE TO YOU FOR DAMAGES, INCLIDING ANY CENERAL, SPECIAL, INDIDENTAL OI CONSEQUENTIAL DAMAGES ANDING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE AND HARDWARE (INCLIDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR INCSESS SUSTAINED BY YOU OF THIRD PARTIES OF A FAILURE OF THE PROGRAM OF OPERATE WITH ANY OTHER PROGRAMOS, EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUICH DAMAGES.

Appearance





Specifications

Processor Quad-core 1.28GHz processor

OS Travis OS

ROM 8G

RAM 1G

Display 2.4" touchscreen

Resolution 240x320 pixels

Wireless charging Supported

Wireless parameters Bluetooth 4.0

Wi-Fi: 802.11 a/b/g/n 4G, 3G, 2G supported

Microphone Built-in ANC dual-microphone

Speaker Built-in high-volume speaker with amplifier

3.5mm audio output supported

Battery 2500mAh

Indicator color Red, blue, green

Dimensions and weight 109*59*17.45mm,118q

Quick guide

How can I set the language?

Travis supports the two-way translation of most languages. You can select the source language and target language as required on the screen for two-way translation*.



On the main screen of translation, touch a national flag icon to select the corresponding language

List of available target languages is displayed* You may touch to select a target language as required

Two-way translation:

Not all pairs of languages support two-way translation.

List of available target languages:

The number of supported languages varies. Online translation supports more than offline translation.

How can I start the translation?

After setting the languages, you can press the translation button to start translation. The "[]" button corresponds to the voice input in language as indicated on the left side of the screen, and the "O" button to that on the right side.



6 7

How can I use the magic button?

The " button between the two translation buttons is the magic button. You can press this button to select the language via voice command.




Step 1 Press the magic button.

Step 2 Speak "Select 'language 1' to 'language 2". (Language 1 and language 2 correspond the language on the left/right side of the screen respectively.)

NOTE

Currently, the voice command in Chinese, English, Spanish, Japanese, Korean, French, German, Russian, Arabic are supported. Voice command in other languages and more features will be launched soon.

8



Touch "②" on the screen or swipe right to view the latest 20 translation records. Touch a translation item to view the detailed content and play back the translation.

How can I adjust the volume?

On the main screen, you can swipe up/down to adjust the volume.



More settings

On the main screen, you can touch "3" or swipe left to access the settings page where you can set the Wi-Fi, cellular data, hot spot and other features.

Safety Instructions

Important Battery Information

Battery: Do not attempt to replace the built-in battery yourself, you may damage the battery, which could cause overheating and injury.

Charging: Charging the device with the included USB cable and power adaptor.

Note: To ensure compatibility, only use accessories recommended by the manufacturer.

Safety and Handling Information

Follow all instructions for installation, use, and maintenance of the device.

Avoid dropping the device. Place it on, a flat and hard surface while not in use.

To clean the device, disconnect power first then gently clean with a soft and dry cloth.

Do not expose the device to any liquid. Whenever your

device gets wet, dry it with a clean, soft cloth.

When the device is suddenly moved from cold to warm
environments, condensation may form in the housing of
the device. Before use, allow the moisture time to
evaporate. Keep the device away from heat sources,
like radiators, heaters, ovens, amolfilers, naked flames

Never obstruct any ventilation openings. Install in accordance with the manufacturer's instruction.

or direct sunlight.

- Do not expose the device to sand or dust, nor cover it with items, such as newspapers, cloths, or curtains.
- Do not operate the device in a closed cabinet. Leave sufficient free space around the device for adequate ventilation.

Do not attempt to repair or service the device yourself. Opening or removing the casing may expose you to electric shock, and other hazards. If repair is required, contact your dealer and refer all servicing to qualified service personnel.

Do not use the device if you notice any abnormality. If any smoke becomes apparent, contact your dealer immediately. Do not try to repair the device yourself.

Avoid using dropped or damaged appliances. If the device is dropped and the housing is damaged, the internal components may not function normally. Stop using the device and contact your dealer for repair. Continued use may lead to fire or electric shock.

To reduce the risk of electric shock, do not touch any connector with wet hands.

Never remove the housing of the device.

Never lubricate any part of the device.

Never place the device on top of other electrical equipment.

Warning: To reduce the risk of electric shock, do not remove the front or back cover.

Recycling Packaging Materials

Observe the local regulations for how to dispose of the packaging materials.

Instructions for users on removal and disposal of

For products with a built-in battery that lasts for the lifetime of the product, removal may not be possible for the user. In this case, recycling or recovery centers must handle the dismartiling of the product and subsequent removal of the battery. Such a procedure should only be performed by authorized service centers. In the European Union and other locations, it is illegal to dispose of any battery with household trash. All batteries must be disposed of in an environmentally sound manner. Centact your local waste-management officials for information regarding environmentally friendly collection, recycling and disposal techniques for used batteries.

Warning: Danger of explosion if battery is incorrectly replaced. To minimize risk of fire or burns, do not disassemble, crush, puncture, or short the external electrical contacts. Do not expose the device to temperatures above 60°C, or dispose of in fire or water. Replace only with specified batteries.

"Separate collection" for all batteries and accumulators will be indicated by the crossed-out wheeled bin, shown below:



Disclaimer



FCC compliance statement

FCC ID: 2AL6P-TT201

This equipment has been tested and found to comply with the ANSI C63.4, and part 15 of the FCC Regulations. This device complies with Part 15 of FCC rules; operation is subject to the following two conditions.

- 1. This device may not cause harmful interference and.
- This device must accept any interference received, including interference that may cause undesired.



CE statement

This product complies with the council RTTE directive 99/5/EC. The CE marking is used to denote compliance with this directive

10